


Teileliste



Pos.	Bezeichnung	Stück	Bestell-Nr.	Preis
1	Pumpenkörper		-	
3	Kolben Ausf. 2		2621-0303-02-00	
3	Kolben Ausf. 3		2621-0303-03-00	
4	Stopfmutter		2621-0304-01-00	
5	O-Ring		2621-0305-01-00	
6	Stützring		2621-0306-01-00	
7	Ansaugstutzen		2622-0307-01-00	
10	Dichtung		2621-0310-01-00	
11	Feder		2621-0311-01-00	
12	Kugel		2621-0312-01-00	
13	Schraube		2622-0313-01-00	
14	Rücklaufschrabe		2621-0314-01-00	
15	Rücklaufschrabe		2622-0315-01-00	
16	Kugel		2621-0317-01-00	
18	Kugel		2622-0318-01-00	
19	Adapter M 10 x 1		2622-0619-01-00	
20	Kolben		2622-0631-01-00	
21	O-Ring		2622-0621-01-00	
22	Stützring		2622-0622-01-00	
23	O-Ring		2622-0623-01-00	
24	Stützring		2622-0624-01-00	
25	Feder		2622-0625-01-00	
26	Achse 5 mm ø		2621-0326-01-00	
27	Sicherung		2621-0327-01-00	
28	Gehäuse		-	
29	Öltank		2622-0329-01-00	
32	Stopfen		2622-0332-01-00	
36	Handhebel		-	
46	Kappe		2622-0646-01-00	
47	O-Ring		2622-0347-01-00	
48	Kugelhalter		2622-0348-01-00	
49	Adapter M 12 x 1		2622-0649-12-00	

Änderungen vorbehalten
2622-0000-01-77