

SUPPLEMENTAL INSTRUCTION SHEET POL-21004-D2 POINT OBSTRUCTION LIGHT

IS21004-D2 21 January 2013 Page 1 of 4

ALARM & TRANSFER

The POL-21004-D2 is a double-headed, steady-burning obstruction light. The two heads are mounted on a powder-coated junction box. The cover of the junction box has a tether and captive screws. One of the lights is normally powered on (the operating head) and one remains on standby. Upon failure of the operating light, power is transferred to the standby light by the included PL10799-X relay. The relay also transfers the POL's Line voltage to the purple alarm wire. This is not an isolated alarm line; if line power fails, this alarm line fails. The alarm line is normally wired to an external alarm lamp, pilot light or other user supplied alarm. It can supply five (5) Amps maximum.

CATALOG NUMBERING SYSTEM

Point Type - Power Photometric Specifications - Color - Mounting & Entries - Style

POL-21004 1: 120V ¹ F: FAA & ICAO A R: Red 34B: ¾-inch, Bottom D2: Alarm & 2: 220V ² B: ICAO B 10B: 1-inch, Bottom Transfer

6: 277V ³ & Transport Canada 34F: ¾-inch, Feed-thru

10F: 1-inch, Feed-thru

Note 1: 120 VAC 50/60 Hz (+/- 20%) Note 2: 220 VAC 50/60 Hz (176-250V) Note 3: 277 VAC 50/60 Hz (+/- 5%)

IMPORTANT: THE POL FIXTURE IS FACTORY SEALED. REMOVING THE CLAMP BAND, LENS OR IN ANY WAY ENTERING THE SPACE CONTAINING THE POWER SUPPLY AND LED ARRAY WITHOUT INSTRUCTIONS FROM THE FACTORY, VOIDS THE WARRANTY AND MAY RESULT IN PREMATURE FAILURE OF THE LIGHT. THE WIRE LEADS ARE SEALED AT THE ENTRY POINT TO THE LED HEAD SUBASSEMBLY. BREAKING THE SEAL OF THE WIRES VOIDS THE WARRANTY.

ALL POL LED UNITS ARE INDIVIDUALLY TESTED AT THE FACTORY BEFORE SHIPMENT. ANY ATTEMPT TO DISASSEMBLE OR TO FIELD TEST THE FUNCTIONS OF THE LIGHT ASSEMBLY VOIDS THE WARRANTY.

WARNING: CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

WARNING: DO NOT INSTALL AIR TERMINALS (LIGHTNING RODS) NEAR OR ON ANY POINT LIGHTING FIXTURES. AIR TERMINALS WILL INCREASE THE POSSIBILITY OF FAILURES AND WILL VOID THE FACTORY WARRANTY. FIXTURE GROUND WIRES MUST NOT BE CONNECTED TO BUILDING/TOWER LIGHTNING PROTECTION SYSTEM DOWN CONNECTORS.

IMPORTANT NOTICE

The installer assumes full responsibility for the proper application and safe installation of this unit in accordance with these instructions, the National Electric Code, and all other state and local codes and practices. POINT LIGHTING CORPORATION accepts no responsibility for damages to property or injury to personnel for the improper use of this product or its failure under any circumstances. POINT LIGHTING CORPORATION's warranty is limited to the replacement of the defective unit only if the failure is the result of a manufacturing defect.



INSTALLATION INSTRUCTIONS

WARNING: TURN OFF THE ELECTRICITY AT THE SOURCE BEFORE INSTALLATION.

The fixture is shipped assembled. Thread the POL's hub to the properly sized conduit. Remove the junction box cover by removing the six (6) screws. The neutral (zero) wire is white. Note: For nominal 220V fixtures, the neutral (zero) wire is blue. Splice the neutral wire to the system neutral (zero). Splice the black wire to the black system line. The green/yellow wire is the fixture's ground; splice it to the system ground. Make splices using proper electrical practices per NEC and local codes in the center condulet after removing the snap-tight cover. POL must be in a vertical position and the individual heads leveled. See "Single POL" above for leveling instructions. Reinstall the junction box cover using the six (6) screws supplied.


REPLACEMENT PARTS

PART NUMBER	DESCRIPTION	QTY
PL10799-1	Relay Alarm 120V	1
PL10799-2	Relay Alarm 220V	1
PL10988	Relay Alarm 277V	1
PL210R4-1F-R-00	Replacement Head FAA & ICAO A 120 V Steady Burning	1
PL210R4-1F-R-04	Replacement Head FAA & ICAO A 120 V Steady Burning Alarm	1
PL210R4-2F-R-00	Replacement Head FAA & ICAO A 220 V Steady Burning	1
PL210R4-2F-R-04	Replacement Head FAA & ICAO A 220 V Steady Burning Alarm	1
PL210R4-6F-R-00	Replacement Head FAA & ICAO A 277 V Steady Burning	1
PL210R4-6F-R-04	Replacement Head FAA & ICAO A 277 V Steady Burning Alarm	1
PL210R4-1B-R-00	Replacement Head ICAO B & Transport Canada 120 V Steady Burning	1
PL210R4-1B-R-04	Replacement Head ICAO B & Transport Canada 120 V Steady Burning Alarm	1
PL210R4-2B-R-00	Replacement Head ICAO B & Transport Canada 220 V Steady Burning	1
PL210R4-2B-R-04	Replacement Head ICAO B & Transport Canada 220 V Steady Burning Alarm	1
PL210R4-6B-R-00	Replacement Head ICAO B & Transport Canada 277V Steady Burning	1
PL210R4-6B-R-04	Replacement Head ICAO B & Transport Canada 277V Steady Burning	1




OUTLINE DIAGRAM POL-21004 DOUBLE

Dimensions: Inches (mm) Depth = 5 (127)



POINT LIGHTING CORPORATION



POINT LIGHTING CORPORATION

Mail: P.O. Box 686, Simsbury, CT 06070
Tel 01 860.243.0600
USA
email: Info@PointLighting.com

Plant: West Dudley Town Rd, Bloomfield, CT Fax 01 860.243.0665 website: www.PointLighting.com



-MT: Marine Treatment



INSTRUCTION SHEET POL-21004 POINT OBSTRUCTION LIGHT

The POL PointSpec series of red LED aviation obstruction lights presents the highest grade technical features and the most options available in the industry. POL steady-burning obstruction lights are used to mark tall structures that present hazards to air navigation. At night, these lights warn pilots when installed in accordance with FAA AC 70/7460-1 and applicable FCC and ICAO rules. Use the PPC photoelectric controller or option -P to provide automatic activation at dusk in accordance with FAA specifications.

CATALOG NUMBERING SYSTEM

Point Type - Power Photometric Standard - Color - Mounting & Entries - Options

POL-21004 1: 120v 1 F: FAA & ICAO A R: Red 34B: 3/4-inch NPT Bottom -S: Single

2: 220v ² B: ICAO B 10B: 1-inch NPT Bottom -NC: NVG Compatible

6: 277v³ &Transport Canada

Note 1: 120 VAC 50/60 Hz (+/- 20%) Note 2: 220 VAC 50/60 Hz (176-250V) Note 3: 277 VAC 50/60 Hz (+/-5%)




CONFORMS TO: UL STD 1598 UL STD 1598A CERTIFIED TO: CSA STD C22.2 No. 250.0

POINT OBSTRUCTION LIGHT POL-21004-1F-R-34B-S

OUTLINE DRAWING POL-21004-1F-34B-S





IMPORTANT NOTICE

The installer assumes full responsibility for the proper application and safe installation of this unit in accordance with these instructions, the National Electric Code, and all other state and local codes and practices. POINT LIGHTING CORPORATION accepts no responsibility for damages to property or injury to personnel for the improper use of this product or its failure under any circumstances. POINT LIGHTING CORPORATION's warranty is limited to the replacement of the defective unit only if the failure is the result of a manufacturing defect.



WARNING: TURN OFF THE ELECTRICITY AT THE SOURCE BEFORE INSTALLATION.

IMPORTANT: THE POL FIXTURE IS FACTORY SEALED. REMOVING THE CLAMP BAND, LENS OR IN ANY WAY ENTERING THE SPACE CONTAINING THE POWER SUPPLY AND LED ARRAY WITHOUT INSTRUCTIONS FROM THE FACTORY, VOIDS THE WARRANTY AND MAY RESULT IN PREMATURE FAILURE OF THE LIGHT. THE WIRE LEADS ARE SEALED AT THE ENTRY POINT TO THE LED HEAD SUBASSEMBLY. BREAKING THE SEAL OF THE WIRES VOIDS THE WARRANTY.

ALL POL LED UNITS ARE INDIVIDUALLY TESTED AT THE FACTORY BEFORE SHIPMENT. ANY ATTEMPT TO DISASSEMBLE OR TO FIELD TEST THE FUNCTIONS OF THE LIGHT ASSEMBLY VOIDS THE WARRANTY.


WARNING: CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

WARNING: DO NOT INSTALL AIR TERMINALS (LIGHTNING RODS) NEAR OR ON ANY POINT LIGHTING FIXTURES. AIR TERMINALS WILL INCREASE THE POSSIBILITY OF FAILURES AND WILL VOID THE FACTORY WARRANTY. FIXTURE GROUND WIRES MUST NOT BE CONNECTED TO BUILDING/TOWER LIGHTNING PROTECTION SYSTEM DOWN CONNECTORS.

INSTALLATION INSTRUCTIONS

1) The fixture is shipped assembled. Thread the POL's hub to the properly sized conduit.

OUTLINE DRAWING



POINT LIGHTING CORPORATION


Mail: P.O. Box 686, Simsbury, CT 06070
Tel 01 860.243.0600
USA
email: Info@PointLighting.com

Plant: West Dudley Town Rd, Bloomfield, CT Fax 01 860.243.0665 website: www.PointLighting.com



2) Electrical connections are to be performed in a suitable junction box. The neutral (zero) wire is white. Note: For nominal 220V fixtures, the neutral (zero) wire is blue. Splice the neutral wire to the system neutral (zero). Splice the black wire to the black system line. The green/yellow wire is the fixture's ground; splice it to the system ground. Make splices using proper electrical practices in suitable splice box per NEC and local codes.

WIRING DIAGRAM



3) The POL must be leveled so the lamp is in a vertical position base-down perpendicular to the mounting surface. If necessary, loosen the three screws that secure the upper head subassembly to the conduit, adjust the position as required and retighten the screws.

POINT LIGHTING CORPORATION

Mail: P.O. Box 686, Simsbury, CT 06070
Tel 01 860.243.0600
USA
email: Info@PointLighting.com

Plant: West Dudley Town Rd, Bloomfield, CT Fax 01 860.243.0665 website: www.PointLighting.com



POWER CONSUMPTION PER POL LED LIGHT HEAD

Array	Туре	Voltage	Watts	mA	VA
-1F	FAA & ICAO A	120	3.48	41.8	5
-2F	FAA & ICAO A	220	4.17	23.85	5.8
-6F	FAA & ICAO A	277	4.09	25.27	7
-1B	ICAO B & Transport Canada	120	6.9	63	7.6
-2B	ICAO B & Transport Canada	220	7.1	34	7.5
-6B	ICAO B & Transport Canada	277	7.5	34	9.4
-1F-NC	FAA & ICAO A -NC Option	120	4.3	40	4.8
-2F-NC	FAA & ICAO A -NC Option	220	4.5	23	5
-6F-NC	FAA & ICAO A -NC Option	277	4.9	22	6
-1B-NC	ICAO B & Transport Canada –NC Option	120	7.7	73	8.7
-2B-NC	ICAO B & Transport Canada –NC Option	220	8	38	8.4
-6B-NC	ICAO B & Transport Canada –NC Option	277	8.3	32	9